

Attach previously unmounted metal brackets with M6 x 20 bolts to the sleeper chaise side.

Attach the chaise backrest to the storage box with 4pcs M6 x 55 bolts.







Place the armrest next to the chaise.

Fix the armrest first with two M6 \times 55 bolts from inside the storage box.



Close the chaise, turn it to the side and fix the armrest from inside the backrest with two M6 x 55 bolts.



Attach the sleeper part with the chaise part as shown on picture. Be sure that the both metal brackets are attached correctly!

Installing the 3 Lumbar cushions.

