

4 (3,5mmX25mm) woodscrews.





Mount them in place by twisting each clock-wise into the pre-drilled holes.



Carefully, turn the sofa upright and ensure each of the legs are installed properly.



Repeat the same process for the 4 legs.



This is how the final product should look like.

