

Open the package and find out legs and assembling parts and tools.



Fasten sofa frame to left and right armrest with a 4 (M6 50 mm) bolts in each side. All bolts fastened from inside out!



Attach each legs with the M6x25mm bolt to align the metal in place then use two screws on each leg.

Place lift and right armrest in place, and open the mechanism completely.



Turn the sofa to the backside.



Insert the non slip furniture pads to the 4 legs.





Carefully, turn the sofa upright and ensure each of the legs are installed properly.



This is how the final product should look like.

