





Now lift up the openable chaise part and attach the backside with 4 (M6x50mm) bolts





Fix the armrest from inside

Attach the legs to the openable chaise The additional leg allways placed to bed side.



Mount the 2 anchors with M6x20mm bolts and 15mm screws as shown in pictures. Use the bolt in upper hole and 2 screws on other holes. Do not overtight the screws!



Put down the bed headside part and attach the bed backside to the chaise backside with 2 (M6x50mm) bolts.



Turn the openable chaise to backside and let the assistant hold the armrest as shown in picture. Fix the armrest to the back from inside the frame with 2 previously removed bolts.



Turn the chaise to the armrest side and mount the 2 screw nuts. Do not overtight them!



Lift up and turn the chaise to the legs. Lift and put the bed to the openable chaise anchors.



Lift up the bed mechanism part and attach the bed at front with butterfly bolt set.

