



Attach previously unmounted metal brackets inverted Attach the chaise backrest to the storage box with M6 \times 20 bolts to the sleeper chaise side.



with 4pcs M6 x 55 bolts.





Place the armrest next to the chaise.

Fix the armrest first with two M6 x 55 bolts from inside the storage box.



Close the chaise, turn it to the side and fix the armrest from inside the backrest with two M6 x 55 bolts.



Note: Opening the chaise will make this process easier

