



Mount the front leg in place and screw the 2 (M6X60mm) bolts into the pre-drilled holes.



Carefully, turn the sofa upright and ensure each of the legs are installed properly.



Mount the support leg in place and screw the 2 (M6X30mm) bolts into the pre-drilled holes.



This is how the final product should look like.

